




Figure 1


LITTLE BALDY WATER COMPANY

Rogers Lake/Antelope Basin Drainage Area

www.keargroundwater.com

(805)845-2700





Explanation

-  California Aqueduct
-  Intermittent Streams
-  Perennial Streams
-  Faults
-  Grandview Canyon Catchment Area
-  LBWC Service Area
-  LBWC Transmission Pipe
-  Antelope Groundwater Basin Boundary
-  Stream Gage (AFA = Acre feet annual average)
-  Boundary of Area Tributary to the Antelope Basin




Figure 2

LITTLE BALDY WATER COMPANY
LBWC Source and Service Area

www.keargroundwater.com

(805)845-2700





Base map source: Leighton and Phillips, 2003

Figure 3

LITTLE BALDY WATER COMPANY

1915 Groundwater Flow

www.keargroundwater.com

(805)845-2700



